

MultiSlicer, multifunctional vegetable slicer with an ergonomic non-slip holder and 3 different blades



Assemble the blade

Carefully put the desired blade inside the handle and safely tuck it in with the help of the side pin on the blade.



Corrugated flakes blade

Can cut potato chips, radish slices or cabbage into 2 mm thin slices the fastest way possible!



Thick wire blade

Can cut potato or cucumber shreds into 3 mm thick wire pieces in no time!



Filament leaves

Can cut shredded radish or carrot into 2 mm filaments for a smooth key!

Specifications

Material: stainless steel

Dimensions: 35,5 x 9,5 cm

Use:

While using this slicer, push the food downward towards the blades rather than pulling towards you because it is 6x faster.

Before cutting long vegetables such as cucumber and carrot, cut them in shorter lengths before slicing. If you have one, use a safety guard for your fingers.

Cleaning: Just remove the blades and wash them under running water with a cleaning brush. We suggest using a cleaning brush to properly remove residue left on the cutter.

Warning

The blades are incredibly sharp, so please be careful while using the slicer. We advise using a safety guard for your fingers.

If you are slicing something small, hold it with your fingers far away from the blades or put your vegetable/fruit on the safety guard.

The MultiSlicer is not suitable for cutting meat.

Children are prohibited from using the product. Please keep the slicer out of the reach of children.

